# Haie

App Driven Clock Radio for iPod®/iPhone® Radio-réveil pour iPod®/iPhone®





Model: IPDS-1
User Manual
Guide de l'Utilisateur
Manual del Usuario Modelo

Thank you for purchasing our Haier product. This easy-to-use manual will guide you in getting the best use of your Docking Speaker.

Remember to record the model and serial number. They are on a label of the main unit.

Model number
Serial number

Date of purchase

Staple your receipt to your manual.

You will need it to obtain warranty service.

#### Dear Customer.

Congratulations on the purchase of this top-quality **Haier** product. As with all **Haier** products, this product has also been developed on the basis of the recent technical standards and manufactured using the most modern electronic components available.

Please take a few minutes to carefully read the following instruction manual before using the equipment for the first time, so that you will be able to enjoy your new **Haier** equipment for a long time.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

### **TABLE OF CONTENTS**

	PAGE
CONTROL	1
IMPORTANT SAFETY INSTRUCTIONS	2
INSTALLING YOUR DOCKING SPEAKER	3
CONTROLS AND CONNECTIONS	4
INSTALL Haier RISE APP	5
Haier RISE APP SETTING	5-8
PRODUCT SPECIFICATIONS	9
TROUBLESHOOTING	9
LIMITED WARRANTY	10-11
IMPORTANT	Back cove

## **IMPORTANT SAFETY INSTRUCTIONS**



Read all of the instructions before using this unit. When using this unit, always exercise basic safety precautions, including the following:

#### **Safety Considerations**

- Ensure that the power cable and other connected cables are protected and are positioned so that they are not likely to be walked on, pinched or damaged.
- Do not position the unit in areas where it may experience humid or damp conditions.
- Do not allow the unit to get wet. You must keep it away from dripping or splashing water.
- Never allow children to insert foreign objects into the holes or slots on the unit.
- Do not cover the ventilation holes with items such as tablecloths or curtains, etc. This may cause the unit to overheat.
- 6. No naked flame sources, such as candles, should be placed on or near the unit.
- 7. Do not place objects filled with liquids, such as vases or jugs, on or near the unit.
- 8. Do not place the unit in a closed cabinet without proper ventilation.

#### Cleaning

- 1. Disconnect the unit from the mains supply before cleaning.
- 2. Do not use any liquids or aerosol cleaners, as this may damage the unit.
- 3. Use a dry, soft, dust free cloth.

#### Servicing

- 1. There are no user serviceable parts in this unit. When servicing, refer to qualified service technician.
- Consult your retailer if you are ever in doubt about the installation/ operation/safety of the product.

#### **INSTALLING YOUR DOCKING SPEAKER**

Carefully remove your **App Driven Docking Speaker** from the box. You may wish to keep the packaging for future use.

#### Package contents:

Inside the box you will find:

- 1. App Driven Docking Speakers (Main Unit)
- 2. Power Adapter
- 3. User Manual and Warranty Card

#### **Positioning your Docking Speakers**

Place your **App Driven Docking Speaker** on a flat and stable surface. Make sure it is not subject to vibrations or movement.

#### Avoid the following locations:


- 1. Where it will be close to heat radiating sources.
- 2. Where humidity is high and/or there will be poor ventilation.
- 3. Where it will be dusty.
- 4. Where it will be damp or a possibility of water dripping or splashing onto the unit

#### Features:


- 1. Plays your iPod / iPhone through the speakers.
- 2. Charges your iPod / iPhone while you listen to music.
- Free Haier Rise application\* from the Apple App store provides additional features.
- App only works with iPhone / iPod with OS 3.0 or above. All iPod / iPhone models with a 30-pin connector will be able to use the basic speaker function.

### **CONTROLS AND CONNECTIONS**

#### **Top View**



#### **Back View**



# **INSTALL Haier** Rise App

For additional features, such as FM radio, alarm, and weather, download the **Haier** Rise App from the iTunes app store.

⇒ Note: You must have the Internet connection to download this application.

# Haier Rise App SETTINGS

After installing **Haier** Rise App, touch the icon to start the application.

#### Choosing an application function:

 Touch one of the icons located at the bottom of the screen to select the function you want.



#### Application help:

If you need help with using the application, touch the help icon at the top of the screen.

There are several help screens available, scroll to reveal them. Touch the  $\bigcirc$  icon to exit the help screens.

# Haier Rise App SETTINGS

#### **CLOCK FUNCTION:**

#### Setting the alarms via the application:

\* Touch the Clock icon to open the clock screen.



- ① Alarm setting icon
- ② Time and date displays
- 3 Alarm time displays
- 4 Location and weather summary

#### **WEATHER FUNCTION:**

\* Touch the Weather icon to launch the weather application.



- ① More detail of the current weather
- ② Weather forecast

From the weather screen you can choose sub-screens that display detailed information of the current weather condition or a weather forecast.

From the detail sub-screens, touch the '< Back' icon to return to the main weather display screen.

# Haier Rise App SETTINGS

#### RADIO FUNCTION:

Select the Radio function from the application menu at the bottom of the screen. The radio screen will be displayed.



- Scroll here to tune the radio (108.0 MHz shown in this example)
- ② Touch here to store a station preset
- 3 Touch here to scan for a station
- Scroll here to change the radio volume
- ⑤ Touch to select a radio preset

You can now operate many functions of your clock radio from the iPhone screen, tuning for stations and storing presets. In addition, you can assign the presets names for easier selection.

#### Auto tuning/preset storing:

\* Touch the AUTO icon to scan for stations and store any stations found in the application preset locations.

**NOTE:** The presets stored by the application are separate and additional to those stored from the control panel.

#### Manual tuning:

 Scroll the frequency wheel to manually tune a station. The upper half of the wheel sets tuning in 1MHz steps, the lower half in 0.1MHz steps.

#### Storing a station as a preset:

- \* Tune to the station you want to store.
- \* Touch the SAVE icon.
- \* Choose a preset number to store this station (touch the M1, M2.... etc icon). The station will be stored.

**NOTE:** You can scroll the preset bar to reveal more preset numbers (up to 20) if required.

#### Naming preset stations:

You can name preset stations stored on your iPhone.

\* Touch the text box below the preset number you want to rename. The text entry keypad will appear.

7



# Haier Rise App SETTINGS

#### **INTERNET RADIO FUNCTION:**

Select the Internet Radio function from the application menu at the bottom of the screen.

The internet radio screen will be displayed.



#### **APPLICATION SETTINGS:**

From the Application setting screen you can choose the following settings -

**Flash colon:** Set to 'ON' for a flashing colon on the clock display.

**Brightness:** Set the display brightness for the application (useful to make the display dimmer when docked at night).

**24 Hour Mode:** Set the clock mode to your preference of 24 hour or 12 hour display.

**Temperature unit:** Choose to set the temperature display units to your preference of Centigrade or Fahrenheit.

**Auto-Lock:** When set to 'ON' with the application running the iPhone will lock automatically after 1 minute of inactivity. When set to 'OFF' the iPhone will not lock while the application is running.

**NOTE:** When Auto-Lock is set to 'OFF' the iPhone display will stay permanently lit when the application is running.

# **Product Specifications**

Power Input	100-240V AC, 50/60Hz
Output Power	5.0V, 2A
Driver Size	1.5 inch
Impedance	4 Ohm
Frequency Response	210Hz-20KHz
S/N Ratio	60dB
Dimensions (DWH)	6.1 $\times$ 3.5 $\times$ 1.0 inch
	(155×88×25 mm)

# **Troubleshooting**

#### If a fault occurs, please check the points listed below:

- Check all cables to ensure they are connected correctly;
- Check if the iPhone / iPod is inserted correctly; undock the player, check for;
- Any obstruction on the connectors and dock again.

### Never try to open the set yourself as this will void the guarantee!

#### LIMITED WARRANTY

This Haier brand product, when shipped in its original container will be free from defective workmanship and materials, and agrees that it will, at its option, either repair the defect or replace the defective product with a new or remanufactured equivalent at to the purchaser, for parts or labor for the periods set forth below:

This warranty does not apply to the appearance of the product or the exterior of the product, which has been damaged or defaced, altered or modified in design or construction. It does not apply to the additional excluded items set forth below:

The warranty commences on the date the item was purchased and the original purchase receipt must be presented and the original purchase receipt must be presented to the authorized service center before warranty repairs

The limited warranty described herein is in addition to whatever implied warranties may be granted to the purchasers by law.

# ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD(s) FROM THE DATE OF PURCHASE SET FORTH BELOW.

Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein, or to extend the duration of any warranties beyond the time period described herein on behalf of Haier.

The warranties described herein shall be the sole and exclusive remedy available to the purchaser. Corrections of defects in the manner and for the period of time described herein, shall constitute complete fulfillment of all abilities and Responsibility of Haier to the purchaser with respect to the product, and shall constitute full satisfaction of all claims, whether based on contract, negligence, strict duality or otherwise. In no event shall Haier be liable, or in any way responsible for any damages or defects in the product which were caused by repairs or attempted repairs performed by anyone other than an authorized service center or dealer; nor shall Haier be liable, or in any way responsible for incidental or consequential economic or property damage. Some states do not allow the exclusion of incidental or consequential damages, so that above exclusion may not apply to you.

# THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Warranty period for this product: 1 year parts and labor.

# Additional items excluded from warranty coverage: non-rechargeable batteries.

#### Where to obtain service:

For the location of the nearest Haier authorized service center or to obtain product literature, accessories, supplies or customer assistance, please call **1-877-337-3639**.

What to do to obtain service: ship or carry in your product to an authorized service dealer or center. Be sure to have proof of purchase.

If you ship the product, be sure it is packaged carefully.

Haier America New York, NY 10018

# **IMPORTANT**

#### Do Not Return This Product To The Store

If you have a problem with this product, please contact the "Haier Customer Satisfaction Center" at 1-877-337-3639. DATED PROOF OF PURCHASE, MODEL # AND SERIAL # REQUIRED FOR WARRANTY SERVICE

# **IMPORTANT**

#### Ne pas renvoyer cet appareil au magasin.

Si vous avez un problème avec cet appareil, veuillez contacter le service à la clientèle de Haier au 1-877-337-3639. IL EST OBLIGATOIRE DE FOURNIR UNE PREUVE D'ACHAT DATÉE, LE NUMÉRO DU MODÈLE ET SON NUMÉRO DE SÉRIE AFIN DE BÉNÉFICIER DE LA COUVERTURE DE LA GARANTIE.

# **IMPORTANTE**

#### No Devuelva Este Producto al Establecimiento Compra.

Si tiene problemas con este producto, por favor póngase en contacto con el 
"Centro Haier de Atención al Cliente" en el 1-877-337-3639.
PARA EL SERVICIO DE GARANTÍA SE REQUIERE PRUEBA DE COMPRA, FECHADA,
No. DE MODELO Y No. DE SERIE



100-240 V. 50/60 Hz

Made in China Fabriqué en Chine Hecho en China



New York, NY 10018

Printed in China